

Installation Manual

Multiwrap



1

Make sure that the service penetration and the gap are free from dust, dirt and grease.

2

Measure the circumference of the service penetration and cut the Multiwrap to size with a knife. Remember to keep an extra length of at least 10 mm to create an overlap.

3

Remove the protective film on the back (1) and wrap the required number of layers of Multiwrap around the service penetration.

4a

Close the remaining gap according to the Multimastic C System or Multimortar System.

4b

Close the remaining gap according to the Multimastic C System or Multimortar System.

5

Fill in the conformity statement and paste it next to the fireproof seal.

¹⁾ It is not necessary to remove the protective film to also push the Multiwrap into the correct position.



Information



For use and for more information about an application, refer to the Mulcol documentation and local and international approvals. See the **Mulcol Fire Protection app** for the correct application in combination with fire resistance, or use our selector at www.mulcol.com
For professional use only.

MULCOL
INTERNATIONAL